
How To Use A Tens Machine

*How To Use
A Tens
Machine*

*Downloaded from
template-dev.mobaptist.org
by Lynn & Rodrigo*

INTRODUCTION TO TENS THERAPY

If you have ever struggled with persistent pain, whether from an old injury, a chronic condition like arthritis, or post-surgical recovery, you have likely searched for relief methods that do not rely solely on medication.

Transcutaneous Electrical Nerve Stimulation, commonly known as TENS therapy, offers a drug-free alternative that many people find

effective. A TENS machine delivers small electrical pulses through electrodes placed on the skin to help manage pain. While the idea of using electricity on your body might sound intimidating at first, learning **how to use a tens machine** is surprisingly straightforward and can become a valuable part of your pain management routine. This guide will walk you through everything you need to know, from preparation to advanced tips, ensuring you use your device safely and

effectively.

WHAT IS A TENS MACHINE AND HOW DOES IT WORK?

A TENS machine is a small, battery-operated device designed to provide **pain relief** by sending mild electrical impulses through the skin. These impulses stimulate the nerves in the treated area, which can help reduce pain signals reaching the brain. The two main theories explaining how TENS works are the Gate Control Theory, which suggests that the electrical impulses block pain signals from traveling to the brain, and the idea that TENS stimulates the production of endorphins, the body's natural painkillers.

Understanding this basic mechanism is important because it influences how you position the electrodes and choose your settings. When you know **how to use a tens machine** correctly, you are able to target specific nerve pathways and maximize the therapeutic benefit.

PREPARING TO USE YOUR TENS MACHINE

Before you begin, take a few minutes to prepare both yourself and your device. Proper preparation ensures safety, comfort, and effectiveness.

Check

Your Device and Supplies

Make sure your TENS machine is fully charged or has fresh batteries. Gather your electrode pads, lead wires, and the instruction manual for your specific model. Check the electrodes for cleanliness and adhesion. If they are worn out or no longer sticky, replace them with new ones. Old electrodes do not conduct electricity well and can cause inconsistent stimulation.

Inspect Your Skin

Your skin should be clean, dry, and free from cuts, rashes, or irritation. Avoid applying lotions, oils, or creams to the area where you will place the electrodes, as these can interfere with adhesion and conductivity. If you have sensitive skin, you may want to test a small area first.

Understa nd Your Pain Source

Identify the exact location and type of pain you want to treat.

TENS is most effective for localized pain, such as a sore muscle, a stiff joint, or a specific area of back pain. If your pain is widespread or comes from a deep internal source, TENS might not be the best option, and you should talk to a healthcare provider.

STEP-BY-STEP GUIDE: HOW TO USE A TENS MACHINE

Now that you are prepared, follow these steps carefully. This process is safe for most people, but always refer to your device manual for model-specific instructions.

Step 1:

Read the Manual

Every TENS machine has different controls, programs, and safety features. Take five minutes to read the manual that came with your device. Look for information on maximum intensity, recommended session duration, and any contraindications listed by the manufacturer.

Step 2: Clean and Prepare

Your Skin Correctly

Wash the area where you will place the electrodes with mild soap and water, then dry it thoroughly. Pat the skin dry rather than rubbing. If the area is hairy, you may need to trim the hair lightly to ensure good electrode contact. Never shave right before application, as this can cause irritation.

Step 3: Place the Electrode S

Electrode placement is one of the most critical aspects of **how to use a tens machine**. The goal is to position the pads so that the electrical current passes through the pain site. Generally, you place one electrode on each side of the painful area, about an inch apart. Do not place them directly over the spine, on the front of the neck, over the eyes, or on broken or infected skin.

For lower back pain, place the electrodes vertically on either side of the spine, at the level of the pain. For shoulder pain, position one pad on the front of the shoulder and one on the back. For knee pain, place one pad above the kneecap and

one below it, on either side. If you are unsure, consult a diagram in your manual or ask a physiotherapist.

Step 4: Connect the Leads

Snap the lead wires onto the electrodes. Then plug the other end of the wires into the TENS machine. Ensure the connections are secure. If your device has two channels, you can treat two areas simultaneously by attaching two pairs of electrodes.

Step 5:

Turn On the Device and Adjust Settings

Start with the machine turned off. Then turn it on and set the intensity to the lowest level. Most TENS machines have adjustable frequency, pulse width, and intensity. For acute pain, a higher frequency (80-120 Hz) is often used. For chronic pain, a lower frequency (2-10 Hz) may be more effective. Pulse width can also be adjusted; a wider pulse sends a stronger

impulse. Increase the intensity slowly until you feel a comfortable tingling or buzzing sensation. You should not feel sharp pain or muscle contractions unless that is your goal. If you feel discomfort, reduce the intensity immediately.

Step 6: Start Your Session

Most TENS machines have a timer, but typical sessions last between 20 and 30 minutes. You can use the device multiple times a day if needed, but avoid using it for more than an hour total in a single day without a break. Some machines have a pulse mode that alternates

between high and low intensity, which can help prevent nerve habituation.

Step 7: After the Session

Turn off the device before removing the electrodes. Gently peel the pads off your skin. Clean the electrodes with a damp cloth if necessary and store them on the plastic liner provided. If your skin looks red or feels irritated, wait for it to heal before using the device again in that area. Wash your skin again to remove any residue.

BEST PRACTICES FOR ELECTRODE

PLACEMENT

Electrode placement can make or break your TENS experience. Here are specific placement strategies for common pain areas.

Lower Back Pain

- Place two electrodes vertically on either side of the spine, about two to three inches apart. The pads should be centered over the painful area.
- Alternatively, place one pad on the lower back and the other on the gluteal muscle on the same side if the pain radiates into

the buttock.

Neck and Shoulder Tension

- Never place electrodes on the front of the neck. Instead, place them on the upper trapezius muscles at the base of the skull.
- For general shoulder pain, position one pad on the front of the shoulder joint and the other on the back of the shoulder blade.

Knee

Osteoarthritis

- Place one electrode above the kneecap and one below it, on the same side of the leg. Alternatively, place them on either side of the knee joint, about two inches apart.
- Avoid placing electrodes directly over the kneecap if it feels bony or sensitive.

UNDERSTANDING TENS MACHINE SETTINGS

Modern TENS machines offer a range of settings that can be adjusted to suit your specific needs.

Knowing what each setting does helps you get the most out of your therapy.

Frequency (Hz)

Frequency controls how many electrical pulses are delivered per second. High-frequency settings (80-120 Hz) are generally used for acute pain and produce a strong, rapid tingling sensation. Low-frequency settings (2-10 Hz) are often used for chronic pain and may cause gentle muscle twitching, which can help release endorphins.

Pulse

Width

Pulse width determines the duration of each electrical pulse. A wider pulse delivers a stronger and deeper stimulus. For superficial pain, use a narrow pulse width. For deeper pain, a wider pulse may be more effective. Most devices have preset combinations of frequency and pulse width.

Intensity

Intensity controls the strength of the electrical sensation. Start low and increase gradually. The ideal intensity is strong but comfortable. You should not feel pain or excessive muscle contraction. If you feel sharp or burning

sensations, lower the intensity immediately.

Mode

- **Continuous Mode:** Delivers a constant pulse. Good for general pain relief.
- **Burst Mode:** Delivers pulses in short bursts, which can feel like tapping. This is often preferred for chronic pain or when you want to prevent the nerves from getting accustomed to the stimulation.
- **Modulation Mode:** Randomly varies frequency and pulse width to prevent nerve adaptation. This can be useful for long sessions.

SAFETY TIPS AND PRECAUTIONS

While TENS machines are generally safe for most people, there are important safety guidelines to follow.

- **Do not use** if you have a pacemaker, implanted defibrillator, or other electronic medical devices, unless cleared by your doctor.
- **Do not use** over the front of the neck, as this can cause a drop in blood pressure or laryngeal spasm.
- **Do not use** over open wounds, rashes, or inflamed skin.
- **Do not use** on the abdomen during pregnancy, especially in the

first trimester.

- **Do not use** while driving, operating machinery, or sleeping.
- **Do not use** over the eyes, over the carotid sinus, or inside the mouth.
- **Keep out of reach** of children and pets.
- **Do not share** electrodes with another person to avoid cross-contamination.

COMMON MISTAKES TO AVOID

Even experienced users can make errors that reduce the effectiveness of TENS therapy. Here are the most common mistakes and how to avoid them.

- **Placing electrodes too close together:** If the pads are too close, the current runs directly from one to the other without passing through the pain site. Ensure they are at least an inch apart.
- **Turning up the intensity too high:** More is not always better. High intensity can cause muscle fatigue, skin burns, or discomfort.
- **Using worn-out electrodes:** Old electrodes do not stick well and can cause uneven stimulation. Replace them regularly according to the manufacturer's instructions.
- **Skipping skin preparation:** Dirty or oily skin reduces electrode adhesion and conductivity.
- **Using TENS for undiagnosed pain:** If you have severe, unexplained, or persistent pain, see a doctor before starting TENS therapy. TENS treats symptoms, not the underlying cause.
- **Not varying settings:** Using the same frequency and intensity every time can lead to nerve habituation, where you stop feeling the

stimulation.
Experiment with
different modes
and settings to
find what works
best.

**WHEN TO
CONSULT A
HEALTHCARE
PROFESSIONAL**
